

MOSN-5.

Revision 0

TO: Distribution

FROM: N.I. Morris

DATE: May 26, 1973

SUBJECT: Operator's Guide to BOS

This MOSN applies to Multics System operation on the Multics
Series Model 6180.

Table of Contents

Description.....	2
Channel Requirements.....	3
Loading BOS.....	4
WARM and COLD cards.....	4
Other Control Cards.....	5
The BOS Toehold.....	6
The BOS Command Language.....	7
BOS Commands.....	10
Control Program Commands.....	10
Disk Loaded Commands.....	11
BLAST.....	13
BOOT.....	14
CONFIG.....	15
CORE.....	17
DIE.....	18
DMP355.....	19
DUMP.....	20
ABS.....	20
CONFIG.....	28
CONT.....	21
D190, D181, D170.....	26
D270.....	25
DBR.....	23
BULK.....	25
CUMP.....	22
EOF.....	27
FILL.....	24
GO.....	28
PATCH.....	28
PROC.....	23
PRT.....	27
QUIT.....	27
REG.....	20
SEG.....	20
STACK.....	21
TAPE.....	27

ESD.....	29
FD355.....	30
FDUMP.....	31
FMT.....	32
IF.....	33
LABEL.....	35
LD355.....	36
LOADDM.....	37
PATCH.....	38
PRINT.....	42
RESTOR.....	43
RUNCOM.....	45
SALV.....	47
SAVE.....	48
TAPED.....	50
TEST.....	51
TIME.....	53
TSTCHN.....	55
WRITE.....	56
Secondary Storage Device Addressing.....	57
Examples.....	59

BOS (Bootload Operating System) is a set of programs for performing functions such as loading the Multics system; core, disk, and bulk store dumping; patching; and normal and emergency shutdown.

BOS consists of five parts:

1. Loader A program loaded from tape which loads the other BOS programs onto the disk.

2. toehold A 400₈ (octal) word program permanently residing in core at location 4000₈.

3. control program A program to perform administrative functions for BOS. These include saving and restoring machine conditions and loading command programs.

4. command programs A number of programs which perform the various functions of BOS.

5. utility package Utility subroutines used by the command programs and accessed through a transfer vector.

Channel Requirements

BOS requires the following IOM peripheral channels for proper operation:

<u>Peripheral Device</u>	<u>IOM Channel #</u>
operator's console	20 ₈
magnetic tape	12 ₈
printer	15 ₈
card reader	16 ₈

BOS will use as much core memory as is available.

Loading BOS

The BOS loader is operated as follows:

1. Place the one card IOM bootstrap loader followed by the loader control cards into the card reader.
2. Mount a BOS system tape at loadpoint on drive 0.
3. Press initialize and reset console.
4. Press bootload

The BOS bootstrap card reads the first program from the tape and transfers control to it. This is the BOS loader, and it will read one or more of the following loading control cards:

WARM disk first last channel area

This tells BOS the portion of the disk where it is to store its various files. disk must be D190, D181, D170, or D270. first is the first 64 word sector to be used, last is the first sector not to be used, channel is the disk channel number, area is the disk unit to use. All numbers are octal.

COLD disk first last channel area

This card performs the functions of the WARM card plus it resets the command directory and clears the configuration deck.

One of these four cards must immediately follow the card bootstrap:

Loading BOS

The BOS loader is operated as follows:

1. Place the one card IOM bootstrap loader followed by the loader control cards into the card reader.
2. Mount a BOS system tape at loadpoint on drive 0.
3. Press initialize and reset console.
4. Press bootload

The BOS bootstrap card reads the first program from the tape and transfers control to it. This is the BOS loader, and it will read one or more of the following loading control cards:

WARM disk first last channel area

This tells BOS the portion of the disk where it is to store its various files. disk must be D190, D181, D170, or D270. first is the first 64 word sector to be used, last is the first sector not to be used, channel is the disk channel number, area is the disk unit to use. All numbers are octal.

COLD disk first last channel area

This card performs the functions of the WARM card plus it resets the command directory and clears the configuration deck.

One of these four cards must immediately follow the card bootstrap:

The BOS Toehold

The BOS toehold is a program which resides in the first 400(8) locations of memory starting at absolute location 4000(8). The toehold communicates very closely with the control program in the following manner:

When Multics is running, the toehold is invoked by manually forcing the processor to execute an XED 4000 instruction. The toehold saves the processor registers and writes the first 20000₈ locations of memory onto the disk. It then reads SETUP, the control program, into locations 4400₈-13677₈ and transfers control to it. The control program saves the remaining core (locations 20000₈ to 37777₈) and reads the first BOS command line from the input stream.

The toehold is also invoked as a result of the GO or CONTIN command issued in BOS. Here, the control program restores the core and machine conditions that it saved and transfers into the toehold. The toehold restores the core and machine conditions that it saved and restarts the program that was originally running.

The toehold program has another feature which should be discussed. When an XED 4000 is executed, the toehold sets a switch indicating that BOS is now operating. If a second XED 4000 is issued, the switch is checked. If the switch is on, the original core image

and machine conditions (referred to as machine image) are not modified. If trouble develops while running BOS, it may be restarted by forcing an XED 4000, retaining the old machine image. When BOS is left as the result of a GO, CONTIN, BOOT, SALV, or ESD command, the switch is turned off.

This feature would make it impossible to take a dump of BOS itself except that an XED 4002 will ignore the switch setting. If BOS is restarted with an XED 4002, the new machine image will be of BOS and can be examined with the DUMP and PATCH commands.

The toehold may also be entered with an XED 4004. This has the same effect as an XED 4000, except that the instruction counter saved in the machine image is increased by one. This allows Multics to enter BOS and later be restarted at the next location. If XED 4000 and XED 4002 should fail, XED 4004 could be manually executed.

BOS Command Language

The BOS control program (SETUP) performs the functions already mentioned plus it loads and executes the BOS commands. A command is executed whenever its name appears as the first field in an input line read by the control program. If a command to the control program turns out to be a runcom file, then that runcom will be executed. (See the description of the RUNCOM command

and machine conditions (referred to as machine image) are not modified. If trouble develops while running BOS, it may be restarted by forcing an XED 4000, retaining the old machine image. When BOS is left as the result of a GO, CONTIN, BOOT, SALV, or ESD command, the switch is turned off.

This feature would make it impossible to take a dump of BOS itself except that an XED 4002 will ignore the switch setting. If BOS is restarted with an XED 4002, the new machine image will be of BOS and can be examined with the DUMP and PATCH commands.

The toehold may also be entered with an XED 4004. This has the same effect as an XED 4000, except that the instruction counter saved in the machine image is increased by one. This allows Multics to enter BOS and later be restarted at the next location. If XED 4000 and XED 4002 should fail, XED 4004 could be manually executed.

BOS Command Language

The BOS control program (SETUP) performs the functions already mentioned plus it loads and executes the BOS commands. A command is executed whenever its name appears as the first field in an input line read by the control program. If a command to the control program turns out to be a runcom file, then that runcom will be executed. (See the description of the RUNCOM command

sources are set to the operator's console. Up to five previous sources are remembered, but only one runcom file may be active at any time. Runcoms initiated by other runcoms return to the input source in use before the first runcom was executed.

After a QUIET OFF command is read, lines read from the card reader or runcom file will be printed on the operator's console. After a QUIET ON or QUIET command, neither these lines nor "BOS AT" messages will be printed.

Any character typed on the operator's console may be erased by following it with a #. Several #'s will erase several characters until the beginning of the line is reached. An entire line may be erased by pressing the input error button.

Any input lines which will be used as commands or control cards will be broken down into their various fields (often referred to as arguments). Fields are separated by one or more blanks. If the first character of a field contains a number, then that field is converted as both an octal and decimal number. Generally, only the octal number is used. If a numeric field is immediately followed by a decimal point, it will be converted only as a decimal number. If a field begins with a non-numeric character, then it is interpreted as a character string. The scanning of fields ends with the first asterisk. The remainder of the line is treated as a comment.

BOS Commands

There are two types of BOS commands: those executed within the BOS control program and those loaded from the bulk store or disk.

Control Program Commands

CONTIN

Format: CONTIN

Purpose: To restore the machine state and continue running an interrupted activity (usually Multics).

Notes: When BOS is entered, the machine state is saved. CONTIN allows these saved conditions to be restored so that Multics can continue running from the point at which BOS was entered.

GO

Format: GO

Purpose: Identical to CONTIN.

LIST

Format: LIST

Purpose: To cause a list to be printed which contains all the current disk resident BOS command programs and runcoms and their device addresses.

Summary of Bulk Store or Disk Loaded Commands

BLAST	print messages to terminals
<hr/>	
BOOT	Multics bootload
<hr/>	
CONFIG	Loads, prints, changes and appends to configuration deck.
<hr/>	
CORE	saves and restores core onto tape
<hr/>	
DIE	destroys BOS
<hr/>	
DMP355	dumps DataNet 355 core storage
<hr/>	
DUMP	segment dumper
<hr/>	
ESD	restarts Multics to do an emergency shutdown
<hr/>	
FD355	writes a DataNet 355 dump into the dump partition
<hr/>	
FDUMP	writes a system dump into the dump partition
<hr/>	
FMT	writes format information on disk packs
<hr/>	

IF	conditionally executes BOS commands
<hr/>	
LABEL	prints tape label
<hr/>	
LOADDM	loads additional or replacement commands into BOS
<hr/>	
LD355	loads DataNet 355 core storage
<hr/>	
PATCH	core disk or bulk store patch
<hr/>	
PRINT	print a tape
<hr/>	
RESTOR	restores contents of secondary storage devices
<hr/>	
RUNCOM	loads, prints and starts a runcom file
<hr/>	
SALV	starts Multics salvager
<hr/>	
SAVE	saves contents of secondary storage devices
<hr/>	
TAPED	produces an octal dump of a tape
<hr/>	
TEST	tests bulk store and disks
<hr/>	

TIME	reads system clocks and does time conversions
<hr/>	
TSTCHN	allows testing of an IOM channel
<hr/>	
WRITE	causes output to be written on operator's console
<hr/>	

Bulk Store or Disk Loaded Commands Descriptions

BLAST

BLAST can be used from BOS to print messages to all consoles dialed into the DataNet 355.

Format: BLAST CRASH

Purpose: When Multics dies and BOS has been entered, this command will cause the canned message MULTICS NOT IN OPERATION AT (time) to be typed to all dialed-in consoles.

Format: BLAST

Purpose: The operator will be asked to type a message. If for some reason Multics will not be up in a short length of time, this command can be used to explain the situation to dialed-in users.

Format: BLAST HANGUP

Purpose: To hang up all consoles.

BOOT

Format: BOOT -number- -name-

Purpose: To initiate a bootload of Multics.

Notes: Additional arguments may be supplied to the boot command. If a number is given, it is the tape drive to boot from. If a name is given, it is the name of the secondary storage partition to be used (as described by a PART configuration card). Normally, the MULT partition will be used.

Format: BOOT COLD

Purpose: This command should be used only by express instructions of the programming staff. It is used to initiate a complete reload of secondary storage.

CONFIG

Format: CONFIG L
(configuration deck)
QUIT

Purpose: To load a configuration deck.

Format: CONFIG A
(additional configuration cards)

QUIT

Purpose: To add more configuration cards to an existent configuration deck.

Format: CONFIG C
(changes to configuration cards)

QUIT

Purpose: To change existent configuration cards. The configuration deck will be searched for each card in the deck of changes. The first card found matching both the first and second fields will be replaced. If no such card is found, the first card matching the first field will be replaced. If no such card is found, the change card will be added to the configuration deck.

Example: Configuration deck:

```
CPU  A  4
MEM  C  200  ON
MEM  D  200  OFF
```

(continued)

Changes:

CPU	B	5		
MEM	D	200	ON	
BULK	O	2048.	2	2

New configuration deck:

CPU	B	5		
MEM	C	200	ON	
MEM	D	200	ON	
BULK	O	2048.	2	2

Format: CONFIG P -arguments-

Purpose: To print the current configuration deck. If arguments are supplied, only selected configuration cards will be printed.

Format: CONFIG D -arguments-

Purpose: To delete selected configuration cards. All occurrences of a specified configuration card will be deleted.

Notes: Whenever a card is read, certain conversions are performed. The results of each conversion are stored in one word of a 15 word array. Any unused words are filled with -1. The first field is stored as a four character ASCII string. If a field contains a number, it is considered to be an octal number and its binary equivalent is stored. If a field contains a number followed by a period, it is considered to be a decimal number and its binary

equivalent is stored.

If a field is a single letter A through H, then the corresponding number 1 through 8 is stored.

Otherwise, the field is stored as a four character ASCII string.

The 15 word array and a word indicating what conversions were performed on each field are packed together to form the internal representation of the configuration deck.

CORE

Format: CORE SAVE n

Purpose: To write the machine registers and core image onto tape n. If n is not given, 1 is assumed.

Format: CORE RESTOR WAIT n

Purpose: To read a tape produced by CORE SAVE. If WAIT is not present, the core image is automatically started. n is an optional tape number, the default is 1.

DIE

Format: DIE

Purpose: To require a subsequent cold boot of BOS. DIE
destroys the data BOS has stored in core and on the
disk insuring that a test version of BOS will not acci-
dentally be used.

DMP355

Format: DMP355

Purpose: To dump on the online printer fault data, trace table contents, and core image from the DataNet 355.

Format: DMP 355 ABS

Purpose: To dump only the core image from the DataNet 355.

Note: The DataNet 355 image is read into BOS and printed. Thus, the printer should be configured to BOS, not to the DataNet 355.

DUMP

Format: DUMP

Purpose: To dump on the online printer or tape the current machine image. Once the dumper is entered the following commands may be read from the input stream (all numbers must be octal):

REG	ABS	SET	STACK	CONT	DUMP	CONFIG
PROC	DBR	FILL				
BULK	D190	D181	D270	D170		
TAPE	PRT	EOF				
QUIT	GO	PATCH				

REG

Format: REG

Purpose: To dump machine conditions and descriptor segment.

Example: REG *Comment

ABS

Format: ABS loc count

Purpose: The ABS request directs the BOS dumper to dump count locations starting from absolute location loc.

Example: ABS 200 1160

(continued)

MOSN- 5.
Revision 0
DUMP (continued)
SEG

Page 21

Format: SEG n

 where: n is a segment number

Purpose: To dump segment n only

Example: SEG 105

STACK

Format: STACK seg offset

 where: seg is a segment number (used as a base).
 offset is an octal offset (used as a stack
 pointer).

Purpose: To dump segment n as stack frames (both forwards and
 backwards) starting from offset.

Notes: If offset is missing, the location of the first stack
 frame is used. If no seg is specified, the contents of
 pointer register 6 in the machine conditions will be used.

Example: STACK 205 1770

CONT

Format: CONT n accesswords

 where: n specifies a segment number. If null, 0 is
 assumed. accesswords are a string of paired fields
 The fields are used to select the segments to be
 dumped. Each element of a paired field is a variable

string of any logical combination of the following letters:

W = write permit E = execute permit

P = privileged procedure A = all (REPW)

These elements specify access bits in the segment descriptor word (SDW) access field. The first element of each pair specifies the SDW access bits which must be ON; the second element of each pair specifies the SDW access bits which must be OFF.

Purpose: To dump all segments selected by accesswords starting with segment n in the descriptor segment specified by a DBR command, if given, or by the DBR value in the machine conditions. The conditions specified by all pairs are OR'ed to determine whether a segment is to be dumped. If no accesswords are specified, then W is assumed.

DUMP

Format: DUMP accesswords

where: accesswords is an optional argument that is a string of paired fields used to select segments to be dumped.

Purpose: To dump the segments specified by accesswords. DUMP accesswords is equivalent to:

REG
CONFIG
CONT 0 accesswords
STACK

PROC

Format: PROC

Purpose: To dump all write permit segments and directories of all running or stopped processes. Any segment common to more than one process will be dumped only with the first process.

Format: PROC LONG

Purpose: To dump all existing processes.

DBR

Format: DBR add word2

where: add is a 24 bit address.

word2 is an optional argument which, if supplied, will set the bound and paged fields in the second word of the DBR.

Purpose: To define the location of the descriptor segment of the process being dumped to begin at address add.
If this command is not given, the DBR in the machine conditions will be used.

DUMP (continued)

Notes: The following bits are set:

Bits 0-23 of the DBR represent the descriptor segment address. They are set by add.

Bits 36-71 are set by second word (see DSBR description in Processor Manual); if missing, the old value is unchanged.

Example: DBR 273 170000000

FILL

Format: FILL name value

where: name is one of the following:

HCDBRL } value is the contents of the upper and lower
HCDBRU }
part of the DBR to be used to find hardcore segments. The default value is obtained from absolute location 5776 in the Multics core image.

SLTSEG value is the segment number of the SLT (segment loading table). The default is 7. The SLT is used to find the segment numbers of other hardcore segments.

PAGE value is ON to page-in pages from the bulk store or disk;

value is OFF to turn this feature off. The

DUMP (continued)

default is ON.

BOS value is ON to dump BOS in core; value
is OFF to dump core image saved on the
bulk store or disk. The default is OFF.

PML value is ON to simulate dynamic page multi-
level; value is OFF to bypass simulation.
The default is ON.

Purpose: To set important segment numbers and options within
the dumper.

BULK

Format: BULK address count
Prints count records beginning at the indicated
Multics sector address.

Format: BULK BOS address count
Prints count 64-word sectors from the indicated
64-word sector address.

Purpose: To print bulk store sectors.

D270

Format: D270 address count
Prints count records beginning at the indicated
Multics record address.

DUMP (continued)

default is ON.

BOS value is ON to dump BOS in core; value
is OFF to dump core image saved on the
bulk store or disk. The default is OFF.

PML value is ON to simulate dynamic page multi-
level; value is OFF to bypass simulation.
The default is ON.

Purpose: To set important segment numbers and options within
the dumper.

BULK

Format: BULK address count
Prints count records beginning at the indicated
Multics sector address.

Format: BULK BOS address count
Prints count 64-word sectors from the indicated
64-word sector address.

Purpose: To print bulk store sectors.

D270

Format: D270 address count
Prints count records beginning at the indicated
Multics record address.

DUMP (continued)

TAPE

Format: TAPE n

where: n is a tape number.

Purpose: To direct dumper output to tape n. The tape is written in BCD mode, one line per record. When the tape is full, it is unloaded. Dumping will continue with the same tape number.

PRT

Format: PRT

Purpose: To direct output to an available printer.

EOF

Format: EOF

Purpose: To write an end of file and unload the output tape if the dumper's output was directed to tape. If the output was directed to the printer, 10 page ejects are given.

QUIT

Format: QUIT

Purpose: To return control to the BOS control program.

DUMP (continued)

Format: D270 BOS area sector count
Prints count 64-word sectors from the indicated area and sector within that area.

Format: D270 PHY eu su sector count
Prints count 64-word sectors from the indicated electronics unit, storage unit, and sector within that unit.

Purpose: To print DSU-270 sectors.

D190, D181, D170

Format: {D190, D181, D170} address count
Prints count records beginning at the indicated Multics record address.

Format: {D190, D181, D170} BOS area sector count
Prints count 64-word sectors from the indicated area and sector within that area.

Format: {D190, D181, D170} PHY unit spindle cylinder track record count
Prints count 64-word sectors from the indicated unit, spindle, cylinder, track, and record.

Purpose: To print DSU-190, -181, and -170 sectors.

DUMP (continued)

TAPE

Format: TAPE n

where: n is a tape number.

Purpose: To direct dumper output to tape n. The tape is written in BCD mode, one line per record. When the tape is full, it is unloaded. Dumping will continue with the same tape number.

PRT

Format: PRT

Purpose: To direct output to an available printer.

EOF

Format: EOF

Purpose: To write an end of file and unload the output tape if the dumper's output was directed to tape. If the output was directed to the printer, 10 page ejects are given.

QUIT

Format: QUIT

Purpose: To return control to the BOS control program.

GO

Format: GO

Purpose: GO causes the machine image which was being dumped
to be restarted.

PATCH

Format: PATCH

Purpose: PATCH causes the BOS patcher to be entered.

CONFIG

Format: CONFIG

Purpose: To cause the current configuration deck to be printed.

(This concludes the BOS dumper commands.)

ESD

Format: ESD

Purpose: To start an emergency shutdown of Multics.

Operation: Sets the PSR to the segment number of emergency_ shutdown and the ILC to 0. This new machine image is restarted.

Note: If the segment number of emergency_shutdown cannot be found in the SLT (Segment Loading Table), a default segment number of 13 will be used.

MOSN-5.
Revision 0

Page 30

FD355

Format: FD355

Purpose: To take a dump of DataNet 355 core and place it in
an appropriate area of the DUMP partition.

FDUMP

Format: FDUMP

Purpose: To take a dump similar to the PROC command of DUMP. Instead of printing segments, they are transferred as binary words into the DUMP partition on the disk. A header to this partition is created which contains the length of the dump, a switch indicating that the dump hasn't been read, the time of the dump, its error report form number, the machine conditions and the segment directory.

If the previous dump hasn't been read by Multics, the operator is asked if he wishes to overwrite the previous dump.

Format: FDUMP n

Purpose: To set the next error report form number to n.

FMT

(TO BE SUPPLIED)

IF

Format

IF $\left\{ \begin{array}{l} \text{SHUT} \\ \text{SWITCH } \underline{\text{mask}} \\ \text{FDUMP} \\ \text{LD355} \end{array} \right\} \left\{ \begin{array}{l} \text{EQ} \\ \text{NEQ} \end{array} \right\} \underline{\text{value command arg1...argn}}$

SHUT causes the Multics system shutdown state to be

tested. Possible values are as follows:

<u>code (octal)</u>	<u>meaning</u>
0	Normal Multics operation (no ESD)
1	EDS part 1 started
2	ESD part 1 completed
3	ESD completed with lock errors
4	ESD completed with no errors
5	Fast Salvager started
6	Fast Salvager finished with errors
7	Fast Salvager finished with no errors
10	(not used)
11	Active Salvager started
12	Active Salvager finished with errors
13	Active Salvager finished with no errors
14	(not used)
15	Regular Salvager started
16	Regular Salvager finished with errors
17	Regular Salvager finished with no errors
20	(not used)
21	Long Salvager started
22	Long Salvager finished with errors
23	Long Salvager finished with no errors

SWITCH mask reads the processor data switches and masks them with the specified octal mask before comparison.

FDUMP tests the success of a previous fast dump.

Possible values are as follows:

IF (continued)

- 0 - FDUMP was never called
- 1 - FDUMP was entered
- 2 - FDUMP was aborted because the dump
partition already contained an old dump
- 3 - the dump was successfully completed

LD355 tests the success of a previous LD355 command.
Its value is non-zero if a previous LD355 command was
successful and zero otherwise.

value is specified as an octal number. It will be
used in a test for equality or inequality depending
on whether EQ or NEQ was specified. If the condition
is met, command will be invoked with the arguments
arg1...argn.

Purpose: The IF command can be used to test the value of
several variables in the Multics and BOS environments.
Another BOS command will be executed conditionally
on the results of the test. It is most useful
within BOS runcom files.

Examples: ESD *TRY TO EMERGENCY SHUTDOWN
IF SHUT NEQ 4 EDUMP *TAKE DUMP IF FAILURE
FDUMP *TAKE FAST DUMP
IF FDUMP NEQ 3 TDUMP *TAKE TAPE DUMP IF FAILURE

LABEL

Format: LABEL -tape_#-

Purpose: Reads tape or drive specified by optional tape_#
(default is drive 1) and prints tape label on BOS
console.

LD355

Format: LD355

Purpose: To load the DataNet 355 core image. The LD355 command should be issued prior to performing a Multics bootload. The programs D355 and B355 will be loaded into DataNet 355 memory. These programs should have been loaded from the BOS tape as if they were BOS commands.

LOADDM

Format: LOADDM n

Purpose: To read the segments from the BOS system tape on
 drive n. These segments become BOS commands and may
 be executed by typing their name (6 characters or
 less). Only the last copy of a command will be remem-
 bered.

PATCH

Format: PATCH

The PATCH command is used by the Multics programming staff or under the direction of a member of the Multics programming staff.

Purpose: To provide a method of examining and modifying the contents of machine registers, core locations, bulk store or disk sectors.

Notes: To call the PATCH program from BOS command level, type:

PATCH

The patcher will be brought into core and will read requests from the input stream.

The two basic patterns for requests are:

address -count-

will examine count locations starting at address.

If count is missing, one location is printed.

SET address val1 -val2-...

will place val1, val2... into successive locations starting with address. If the input stream is in the QUIET OFF mode, then the old and new contents are printed.

Address may take several forms:

MOSN- 5.
Revision 0

- 1) an absolute address
- 2) segment number | offset
(blanks must surround the |)
- 3) PRn | offset
- 4) a machine register from the list: A, Q, E, TR, XC,
X1, X2, X3, X4, X5, X6, X7, AP, AB, BP, BB, LP,
LB, SP, SB, PSR, ILC, DSBR, INT, PRn (n = 0, ..., 7)

- 5) MCM port

port is the port number of the memory controller

- 6) address request offset

Will reference a secondary storage device. The possible forms for address request are:

BULK Multics device address

{D190, D181, D170, D270} Multics device address

BULK BOS sector

{D190, D181, D170, D270} area sector

D270 PHY electronics unit storage unit sector

{D190, D181, D170} PHY unit spindle cylinder track record

A Multics device address is in the form found in a file map. sector is a 64 word address within an area.

A D270 area is one storage unit. They are numbered 0 to 23 with 0 to 4 in the 0th electronics unit, 5 to 11 in the 1st electronics unit, etc.

PATCH (continued)

A D190, D181 or D170 area is the disk drive unit number.

The address request is described in greater detail in the section on Secondary Storage Device Addressing.

7) BOS command location

This will reference a location in a BOS command.

The character "." may be used to represent the previous address which was examined or set. The operators "+" and "-" may be used between any numbers of "." with the obvious effect. All numbers are octal and must be surrounded by blanks.

PATCH will also accept the following commands:

GO causes the machine image to be restarted.

DUMP enters the BOS dumper

DBR add word2. The DBR value used

in the simulated appending is
changed. (See the DUMP command
for a more complete description.)

QUIT return to BOS.

FILL changes various values and options.
(See the DUMP writeup for a
complete description.)

PUNCH An argument of ON will cause all
patch requests to be punched onto
cards. OFF will suspend punching.

MOSN- 5.
Revision 0

PRINT

Format: PRINT

Purpose: PRINT will print tapes produced by the BOS dumper.

The procedure for using it is:

- 1) Type the BOS command PRINT.
- 2) Mount the tape on drive 1.
- 3) Printing will continue until an EOF is read.

The tape is then unloaded.

- 4) Additional tapes may be printed by mounting them on the appropriate drives.

- 5) After all tapes have been printed, pressing REQUEST on the operator's console will re-enter BOS.

Tape errors are retried and, if persistent, a comment is printed on the operator's console. Printing will then continue.

RESTOR

Format: RESTOR -address extent- -TAPE n-

Purpose: To reload the bulk store and disks from a set of tapes written by SAVE. The arguments are the same as those for SAVE (except ALL has no meaning). The tape headers contain the state of the ALL option along with a copy of the fsdct. See the section on Secondary Storage Device Addressing for the format of address extent. If address extent arguments of the RESTOR don't match those of the SAVE, the following actions take place:

- 1) The record address ranges of this tape and all following tapes are printed.
- 2) The record address ranges of the RESTOR's address extent are printed.
- 3) The operator is asked if this is the correct tape. If answered NO, control is returned to BOS.
- 4) If answered YES, the operator is asked if entire tape(s) should be loaded.
- 5) If answered YES, the RESTOR's address extent is changed to equal the address extent of the tape(s) resulting in all of the tape(s) being

RESTOR (continued)

read. Otherwise, the RESTOR is executed as originally indicated on the command line.

Examples: The input tapes in each example were produced by typing SAVE only.

RESTOR BULK DEVICE

will restore the bulk store only from tapes containing an entire save if the two questions asked of the operator are answered YES and NO respectively.

RESTOR D170 1234 RECORD

will restore only DSU-170 record 1234.

RESTOR TAPE 3

will continue a restore from tape 3 if both questions are responded to with a YES.

RUNCOM

Format: RUNCOM LOAD name

This command will load card images containing command lines until a RUNCOM END card image is found. The file name is added to the BOS command directory and the runcom file is written on the disk.

A LIST command will list runcom files along with the regular BOS commands. (Runcom files may not be loaded from tape.)

Purpose: To manage BOS RUNCOM files. A runcom file contains a predefined sequence of commands which can be automatically executed.

Format: RUNCOM PRINT name

The RUNCOM file name is printed.

Format: RUNCOM SKIP name

Successive lines of the runcom file will be printed and the keyboard unlocked after each. If the runcom line is not to be executed, press EOM and the next line will be printed. Once the correct line is reached, type GO and execute will begin with this line. The first line executed must be a command to BOS.

RUNCOM (continued)

Format: name

A runcom file may be executed by simply typing its name as a command to BOS. This forces the execution of RUNCOM RUN "name".

Format: RUNCOM PUNCH name

The runcom file will be punched out.

Format: RUNCOM EDIT name

The runcom editor is entered to edit the runcom file name. The commands to the editor are:

- Pn Print n lines from pointer. Leave pointer at next line.
 - Dn Delete n lines from pointer. Leave pointer at next line.
 - I Enter Input Mode. Lines input are inserted before current line. Exit from input mode via blank line.
 - Bn Back up n lines from current line or to top of file
 - Nn Go forward n lines from current line or to bottom of file
 - W (name) Writes out file with optional name if desired.
 - Q Exit from editor
-

MOSN- 5.
Revision 0

Page 47

SALV

Format: SALV

Purpose: To start the salvager by forcing the execution of
BOOT WARM SALV 2.

SAVE

Format: SAVE -address extent- -ALL- -TAPE n-

If present, the arguments must be in order given.

See the section on Secondary Storage Device Addressing for a description of the address extent.

Normally, SAVE will write onto tape only those secondary storage records which currently contain useful data.

This is done by using a system-maintained table of assigned records called the fsdct. The fsdct will contain valid information only after a successful system shutdown or salvage. If for some reason a salvage cannot be performed, SAVE may be instructed to ignore the fsdct contents and save all secondary storage records by use of the optional ALL argument. If the ALL argument is not present, a successful shutdown or salvage must have preceded the SAVE.

Purpose: To write the contents of the disks and bulk store onto tape. Unless told to do otherwise, SAVE will copy the contents of all devices in the Multics partition onto tapes 1, 2, etc. As each tape is started, the device name and the address of the first record is printed. This may be used to restart the save at the beginning of a tape or to find the tape which contains a particular record.

Examples: SAVE PART DUMP ALL

 will save the dump partition only.

 SAVE BULK DEVICE

 will save the bulk store only.

 SAVE D270 AREA 5 AREA ALL

 will save all of the 5th DSU-270 unit.

 SAVE D170 5634 ON TAPE 5

 will continue a save starting with tape 5,

 DSU-170 record 5634, and continue to the end.

TAPED

Format: TAPED n

Purpose: To dump the contents of tape n in octal. The tape must be written in binary mode. TAPED will print "EOF" and "ERROR" whenever they occur. TAPED recognizes no end-of-tape marks. TAPED may be stopped by pressing the REQUEST button.

TAPED

Format: TAPED n

Purpose: To dump the contents of tape n in octal. The tape must be written in binary mode. TAPED will print "EOF" and "ERROR" whenever they occur. TAPED recognizes no end-of-tape marks. TAPED may be stopped by pressing the REQUEST button.

n1 n1 n1 n1 ...

n1 n2 n1 n2 ...

n1 n2 n3 n1 n1 n2 n3 n1 ...

n1 n2 n3 n4 n1 n2 n3 n4 ...

MARK The first data word to be checked
 or written will contain the device
 number and device address. The
 remaining words of each record will
 be zero.

Note: TEST may be stopped at any time by pressing the
 REQUEST button.

MOSN-5.
Revision 0

Page 55

TSTCHN

Format: TSTCHN

Purpose: To test an IOM channel. This command is intended
for special use by the programming staff. Its usage
is described in the program listing.

WRITE

Format: WRITE text

Everything on the command line following the
first six characters is typed out.

Format: WRITE ALERT

The audible alarm is turned on.

Purpose: To write a line of text on the operator's console
or to turn on the audible operator alarm.

Secondary Storage Device Addressing

The arguments supplied to the SAVE, RESTOR, or TEST commands which specify secondary storage addressing are called an address extent.

An address extent is:

extent request

(In this case the default partition of MULT is used.)

or

PART partition name extent request

An extent request is:

address request RECORD

to handle one secondary storage record

or

address request AREA

to specify the rest of an entire area

or

address request DEVICE

to specify the rest of an entire secondary storage device
(as specified on the appropriate PART card).

or

address request ON

to specify all secondary storage following a given point
(as specified on the appropriate PART card).

or

address request TO address request

to specify lower and upper secondary storage address limits.

(The upper limit and the first secondary storage address

not desired.)

An address request specifies a starting (or ending) point. It is a secondary storage device address in one of the several following forms:

device name

or

device name AREA area number

to specify a particular physical device area.

or

device name record number

to specify a Multics (1024 word) record number.

or

device name BOS area number record number

to specify a BOS (64 word) record number.

or

device name PHY physical device address

to specify a physical device address. The format of

physical device address is dependent on the particular device.

Secondary Storage Device Addressing
continued

The currently acceptable device names are:

BULK

D190

D181

D270

D170

physical device addresses are specified as follows:

for DSU-270:

electronics unit storage unit sector

for DSU-190, DSU-181 and DSU-170:

disk unit spindle cylinder track record

Examples:

1. To save an entire partition:

SAVE PART PAGE ALL

This command will save all secondary storage records described by the PART PAGE configuration CARD.

2. To restore an entire device:

RESTOR D170 DEVICE

This command will restore (from tape) all records on the DSU-170 disk.

3. To test a physical device area:

TEST D270 AREA 14 AREA

This command will read all records on DSU-270 area 14.

4. To save all the records beyond a given record:

SAVE 270 12345 ON

This command will save all records starting from record 12345 on the DSU-270 disks.

5. To restore a group of records:

RESTOR D270 1122 to D270 1127

This command will restore DSU-270 records 1122 through 1126, inclusive.