

MOSN-232

TO: DISTRIBUTION
FROM: R. B. Snyder
DATE: March 14, 1972
SUBJECT: New 355 Dumper

The current BOS command to dump the 355, DUMP3, is being replaced with a new BOS command, DMP355. If the 355 crashes, it should be dumped using this command. The dump is printed in three sections, fault registers, trace table contents, and memory in octal, ibm bcd, and ascii. If for some reason the dump should fail, DMP355 can take one argument, "ABS" (typed as DUMP355 ABS). If this is typed, only memory will be printed and not the registers or trace table. The ABS option should be used only if the normal dump (typed as DMP355 with no arguments) should fail.